

Crankset		BSA (Standard Threaded)	Shimano Pressfit (BB92/BB107)	PF30	BB30	Specialized OSBB	BBright	BB386	BB95 (Trek standard)	
Cinch System BB Spacing	 <p>Comments: RF Cinch 30mm Crank</p>	 <p><b>Race Face Cinch BB</b></p>	 <p>Comments: RF BB Part number: 68/73mm - BBBSA7330B6 83mm - BBBSA8330B6 100mm - BBBSA10030B6 Install Tool - D30146</p>	 <p>Comments: RF BB Part number: BB89.5/92 - BB419230B7 BB104.5/107 - BB4110730B7 Install Tool - Headset Press</p>	 <p>Comments: RF BB Part number: 68/73mm - BB467330B8 83mm - BB468330B8 Install Tool - Headset Press</p>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>
	  <p>RF SPACER KIT + E-13 BSA30</p> <p>Comments: E-13 BSA BB + RF Spacers: Spacer PN - D30331 x 2 DS width - 1.5mm (1x1.5) NDS width - 1.5mm (1x1.5)</p>	  <p>RF SPACER KIT + E-13 BB92</p> <p>Comments: E-13 BSA BB + RF Spacers: Spacer PN - D30331 x 2 DS width - 1.5mm (1x1.5) NDS width - 1.5mm (1x1.5)</p>	  <p>RF SPACER KIT + COMPETITOR 73mm PF30 BB</p> <p>Comments: Competitor BB + RF Spacer Kit: Spacer Kit PN - F10010 DS width - 14mm (1x11.5,1x2.5) NDS width - 11.5mm (1x11.5)</p>	  <p>RF SPACER KIT + COMPETITOR 73mm BB30 BB</p> <p>Comments: Competitor BB + RF Spacer Kit: Spacer Kit PN - F10010 DS width - 14mm (1x11.5,1x2.5) NDS width - 11.5mm (1x11.5)</p>	  <p>RF SPACER KIT + Specialized 84.5mm OSBB</p> <p>Comments: Specialized BB + RF Spacer Kit: Spacer Kit PN - F10013 DS width - 6.5mm (1x1.5,2x2.5) NDS width - 5mm (2x2.5)</p>	  <p>RF SPACER KIT + COMPETITOR BBRIGHT BB</p> <p>Comments: Competitor BB + RF Spacer Kit: Spacer Kit PN - F10012 DS width - 14.0mm (1x11.5,1x2.5) NDS width - 0mm</p>	  <p>RF SPACER KIT + COMPETITOR BB386 BB</p> <p>Comments: Competitor BB + RF Spacer Kit: Spacer Kit PN - F10011 DS width - 7.5mm (3x2.5) NDS width - 5.0mm (2x2.5)</p>	<b>X</b>	<p>Comments: Not Compatible</p>	